



<u>NOTES:</u>

- 1. ALL DIMENSIONS IN MILLIMETRES UNLESS OTHERWISE NOTED.
- 2. NOMINAL DIMENSION SHOWN. DIMENSION OF HEIGHT AND SCREW LOCATIONS TO BE CONFIRMED FOR NOMINATED CONTROL PANEL.
- 3. CONTROL PANEL TO BE FIXED TO MOUNTING POST IN ACCORDANCE WITH MANUFACTURERS INSTRUCTIONS.
- 4. ISOLATION SWITCH TO BE FITTED TO 40 x 40 UNISTRUCT BRACE.
- 5. ANY EXTERNAL GENERATOR POINT TO BE FITTED TO CONTROL PANEL AS PER MANUFACTURERS REQUIREMENTS.
- 6. TO BE USED WHERE DISTANCE FROM TANK TO HOUSE >10M. SEE NOTE 3 PSS-1100-V
- 7. INSTALL SHROUD TO COVER ALL ELECTRICAL CONDUITS

JSTRALIA	NOT TO SCALE		HT
POST	PSS-1104-V		Сорукідн
	ISSUED 2017	VERSION 2.0	